


SR-Ket-A Series Energy Storage System

User Manual

V1.1



1. Instructions

Thank you very much for choosing the SR-Ket-A series Industrial and commercial energy storage system developed and produced by our company. Please read and understand all contents of the Manual carefully before installing and using the product. If you have any suggestions during the use, please do not hesitate to give us feedback.

1.1 Range of Application

The installation and user manual of SR-Ket-A series is applicable to the installation and use of the following products:

| No | Model | Rated energy | Rated Voltage | Composition |
|----|-----------|--------------|---------------|--------------------------------|
| 1 | SR-Ket20A | 20.5kWh | 204.8V | SR-HOC05B * 4 + SR-PDU100 * 1 |
| 2 | SR-Ket30A | 30.7kWh | 307.2V | SR-HOC05B * 6 + SR-PDU100 * 1 |
| 3 | SR-Ket40A | 41.0kWh | 409.6V | SR-HOC05B * 8 + SR-PDU100 * 1 |
| 4 | SR-Ket50A | 51.2kWh | 512.0V | SR-HOC05B * 10 + SR-PDU100 * 1 |
| 5 | SR-Ket60A | 61.4Kwh | 614.4V | SR-HOC05B * 12 + SR-PDU100 * 1 |

The product should be used in compliance with local standards, laws and regulations, because any non-compliance with the use may lead to personal injuries and property loss.

The drawings provided in this Manual are used to explain the concepts related to the product, including product information, installation guide, electrical connection, system debugging, safety information, common problems and maintenance, etc.

The internal parameters of this product have been adjusted before delivery. No internal parameters can be changed without permission. Any unauthorized changes to the settings will invalidate the warranty, and the Company will not be liable for any loss resulting therefrom.

These Manual and other related documents are an integral part of the product and should be kept properly for onsite installation personnel and related technical personnel to consult.





1.2 Meaning of Abbreviations

| | |
|-----|---------------------------|
| AC | Alternating Current |
| DC | Direct Current |
| PV | Photovoltaic |
| BMS | Battery Management System |
| EMS | Energy Management System |
| BMU | Battery Management Unit |
| BCU | Battery Cluster Unit |

| | |
|-------|-------------------------------|
| BAU | Battery Array Unit |
| PDU | Power Distribution Unit |
| PCS | Power Conversion System |
| RJ45 | Registered Jack 45 |
| SOC | State Of Charge |
| C | Charge C-rate |
| RS485 | RS485 Communication Interface |
| CAN | Controller Area Network |
| SOH | State Of Health |
| DOD | Depth Of Discharge |

1.3 Symbol Stipulations



There may be following symbols herein, and their meanings are as follows.













| Symbols | Description |
|---|--|
|  | Indicate a hazard with a high level of risk which, if not avoided, will result in death or serious injuries. |
|  | Indicate a hazard with a medium level of risk which, if not avoided, could result in death or serious injuries. |
|  | Indicate a hazard with a low level of risk which, if not avoided, could result in minor or moderate injuries. |
|  | Warning information about device or environment safety. If not avoided, equipment damage, data loss, performance degradation or other unanticipated results may be resulted in. The "NOTICE" does not involve any personal injuries. |

2 Safety Precautions

2.1 Safety Symbols

This product contains the following symbols, please pay attention to identifying.

| Symbols | Description |
|---|------------------------------------|
|  | Observe enclosed documentation |
|  | Danger. Risk of electric shock! |

| | |
|---|--|
|  | Danger of high voltages. Danger to life due to high voltages in the Energy storage system |
|  | Hot surface |
|  | CE certification |
|  | Do not touch the product in 5mins after shutdown |
|  | Comply with RoHS standard |
|  | The Energy storage system should not be disposed together with the household waste. |
|  | Flammability risk |
|  | Electric shock hazard |
|  | Keep the battery away from open flame or ignition sources |
|  | Keep the battery away from electric sparks |
|  | Recycling |
|  | Rainproof and moisture-proof |

2.2 General Safety









2.2.1 Important Notice

Before installing, operating, and maintaining the device, please read this Manual first and follow the symbols on the device and all the safety precautions in this Manual.

The matters indicated with "DANGER", "CAUTION", "ATTENTION" and "NOTICE" in this Manual do not represent all the safety matters to be observed but are only the supplements to all the safety precautions. The Company will not be liable for any violation of general safety operating requirements, or any violation of safety standards for the design, production, and use of the device. The device must be used in an environment that meets the requirements of the design specifications. Otherwise, the device may fail, and the abnormal device function or component damage, personal safety accident, and property loss arising from this are not covered within the quality assurance scope of the device. When installing, operating, and maintaining the device, the local laws, regulations, and codes shall be followed. The safety precautions in this Manual are only supplements to local laws, regulations, and codes. The Company shall not be liable for any of the following circumstances.

- The device is not run under the conditions of operating described in this Manual.
- The installation and operating environment is beyond the requirements of relevant international or national standards.
- The product is disassembled or changed, or the software code is modified without authorization.
- The operation instructions and safety warnings related with the product and in the documents are not followed.
- Damage of the device is caused by abnormal natural environment (force majeure, such as earthquake, fire, and storm).
- Transportation damage is caused during customer's own transportation.
- The storage condition does not meet the requirements of the product related documents and causes damage.

2.2.2 General Requirements

| | |
|---|--|
|  | Operating when the power is on is strictly prohibited during installation. |
|  | It is strictly prohibited to install, use, and operate any outdoor equipment or cables (including but not limited to transporting equipment, operating equipment and cables, plugging and removing signal ports connected to the outdoor, working at altitude, and outdoor installation) in severe weather, such as thunder, rain, snow, and gale level 6. |
|  | In case of any fire, evacuate the building or equipment area and press the fire alarm bell or dial the fire call. Under any circumstances, re-entry into a burning building is strictly prohibited. |
|  | Under no circumstances should the structure and installation sequence of the device be changed without the manufacturer's permission. |
|  | The battery terminal components shall not be affected during transportation. And, the battery terminal bolts shall not be lifted or transported. |
|  | It is strictly prohibited to alter, damage or block the marks and nameplates on the device. |
|  | The composition and working principle of the entire photovoltaic power generation system, as well as the relevant standards of the country/region where the project is located shall be known fully. |
|  | After the device is installed, the empty packing materials, such as cartons, foam, plastics, and cable ties, shall be removed from the device area. |

2.2.3 Personnel Safety

- When operating the device, appropriate personal protective equipment shall be worn. If any fault that may lead to personal injury or damage of the device is found, immediately terminate the operation, report to the responsible person, and take effective protective measures.
- Before using any tools, learn the correct method of using the tool to avoid injuries and damage of the device.
- When the device is running, the temperature of the case is high, which may cause burns. Therefore, do not touch the case.
- In order to ensure personal safety and normal use, reliable grounding should be carried out before use.
- Do not open or damage the battery. The electrolyte released is harmful to skin and eyes, so avoid touch it.
- Do not place irrelevant items on the top of the device or insert them into any part of the device.
- Do not place flammable items around the device.
- Never place the battery in the fire to avoid explosion and prevent the personal safety from being endangered.
- Do not place the battery module in water or other liquids.
- Do not short-circuit the battery terminals, because short-circuiting of the battery may cause combustion.
- The battery may pose a risk of causing electric shocks and large short-circuit currents. When using the battery, the following precautions should be paid attention to:
 - a) The metal objects, such as watch and rings, shall be removed.
 - b) Tools with insulated handles should be used.
 - c) Rubber gloves and shoes should be worn.
 - d) The charging power supply shall be disconnected before connecting or disconnecting terminals of the battery.
 - e) Check whether the battery is accidentally grounded. If the battery is accidentally grounded, remove the power supply from the ground.
- Do not clean the internal and external electrical components of the cabinet with water or detergent.
- Do not stand, lean or sit on the device.
- Do not damage any modules of the device.

2.3 Personnel Requirements

- The personnel in charge of installation and maintenance must be strictly trained to understand all safety precautions and master proper operation methods.
- Only qualified professionals or trained personnel are allowed to install, operate and maintain the device.

- The personnel who operate the device, including the operators, trained personnel and professionals, must have special operation qualifications required by the local country, such as high voltage operation, working high above the ground, and special equipment operation qualification.
- The replacement of device or components (including software) must be carried out by professionals or authorized personnel.

2.4 Electrical Safety

2.4.1 General Requirements



Before carrying out electrical connections, ensure that the device is not damaged, or an electric shock or fire may occur.



Never install or remove any power cables when the power is on. The electric arcs or sparks may be generated at the moment when the power cable contacts with the conductor, which may cause fire or personal injuries.

- All the electrical connections must meet the electrical standards of the country/region where the project is located.
- The cables prepared by users themselves shall comply with local laws and regulations.
- Special insulating tools should be used in high-voltage operations.
- Before connecting the power cord, ensure that the label identification on the power cord is correct.
- Operations on the device are allowed only five minutes after the device is completely powered off.
- The insulation layer of the cable may be aged or damaged when the cable is used in a high temperature environment. Therefore, the distance between the cable and the heat source must be at least 30mm.
- Cables of the same type should be bundled together. Whereas the cables of different types should be routed at least 30mm apart, and shall not be wrapped together or crossed.

2.4.2 Grounding Requirements



- When installing the device to be grounded, the protective grounding wire must be installed first; when removing the device, the protective grounding wire must be removed at last.
- It is forbidden to destroy the grounding conductor.
- It is forbidden to operate the device without a grounding conductor installed.
- The device shall be permanently connected to the protective grounding wire. Before operating the device, electrical connection of the device shall be checked to ensure that the device is reliably grounded.

2.5 Installation Environment Requirements

- Do not install or use this product in an environment where the temperature is lower than -10 °C or higher than 50 °C.

- It should be installed in a dry and well-ventilated environment to ensure good heat dissipation performance.

- The product can be installed at a maximum altitude of 3,000m.
- The installation position should be away from the fire source.
- The product should be installed and used away from children and animals.
- The installation position should be far away from water sources, such as faucets, sewer pipes, and sprinklers, to avoid entering of water.
- The device should be placed on a firm and flat supporting surface.
- Do not place any inflammable or explosive items around the device.
- When the device is running, do not block the ventilation vent or heat dissipation system to prevent fire caused by high temperature.



The operation and service life of the energy storage is related to the operating temperature. The energy storage should be installed at a temperature equal to or better than the ambient temperature.



Max+50°C



Min-10°C



RH.+5%~+95%

3 Product Introduction

3.1 Battery System Specifications

| Product model | SR-Ket20A | SR-Ket30A | SR-Ket40A | SR-Ket50A | SR-Ket60A |
|------------------------------------|---|-----------|-----------|-----------|-----------|
| Battery Module Qty in series | 4 | 6 | 8 | 10 | 12 |
| Rated voltage | 204.8V | 307.2V | 409.6V | 512.0V | 614.4V |
| System Operating Min.Voltage | 179.2V | 268.8V | 358.4V | 448.0V | 537.6V |
| System Operating Max.Voltage | 233.6V | 350.4V | 467.2V | 584.0V | 700.8V |
| System Energy | 20.5kWh | 30.7kWh | 41.0kWh | 51.2kWh | 61.4kWh |
| Usable Energy | 19.5kWh | 29.2kWh | 38.9kWh | 48.6kWh | 58.4kWh |
| Recommend Charge/Discharge Current | 50A | | | | |
| Max Charge/Discharge Current | 70/100A | | | | |
| Peak Discharge (3S,25°C) | 80/120A | | | | |
| Installation Location | Rack Mounting | | | | |
| Recommend Depth of Discharge | ≤95% | | | | |
| Life cycle (25°C,0.5C/0.5C,EOL70%) | 6000 Cycles | | | | |
| Display Type | LED+Touch LCD | | | | |
| Triple Protection | Positive Relay + Negative Relay + Breaker | | | | |
| Number of Main Circuit Relays | 3 | | | | |
| Heat Dissipation | Natural Cooling | | | | |
| Working Temperature | Charge:0 ~ 55°C/Discharge:-20 ~ 55°C | | | | |
| Storage time / temperature | 6 months @25°C;3 months @35°C;1 months @45°C; | | | | |
| Communication interfaces | CAN/RS485//WIFI | | | | |
| Humidity | 5%~80%RH | | | | |
| Altitude | ≤3000m | | | | |
| Enclosure protection rating | IP20 | | | | |
| Operation Environment | Indoor | | | | |
| Noise | < 30dB | | | | |
| Max. number of parallel | 2 | | | | |
| Dimensions (L*W) | 776*552mm | | | | |
| Dimensions (H) | 976mm | 1282mm | 1588mm | 1894mm | 2200mm |
| Weight Approximate | 209kg | 305.7kg | 402.4kg | 499.1kg | 595.8kg |
| Cover An Area | 0.78*0.55 m*m | | | | |
| Lithium Battery Standard | UN38.3, MSDS, EN55032, EN55024, | | | | |

3.2 Battery Pack Module Specifications

| | |
|------------------------------------|---|
| Battery Pack Module | SR-HOC05B |
| Cell chemistry | LiFePO4 |
| Battery Energy | 5.12kWh |
| Rated Voltage | 51.2V |
| Rated Capacity | 100AH |
| Recommend Charge/Discharge Current | 50A |
| Max Charge/Discharge Current | 70/100A |
| Peak Discharge(2 mins, 25°C) | 80/120A |
| Installation Location | Rack Mounting |
| Recommend Depth of Discharge | ≤95% |
| Life cycle (25°C,0.5C/0.5C,EOL70%) | 6000 Cycles |
| Heat Dissipation | Natural Cooling |
| Working Temperature | Charge:0 ~ 55°C/Discharge:-20 ~ 55°C |
| Storage time / temperature | 6 months @25°C;3 months @35°C;1 months @45°C; |
| Enclosure protection rating | IP20 |
| Dimensions | 603*485*140mm |
| Weight Approximate | 43.6kg |

3.3 PDU Module Specifications

| | |
|------------------------|---------------|
| PDU Module | SR-PDU100 |
| Rated Voltage | 850V |
| Rated Current | 100A |
| Operating Voltage | 100~850V |
| CAN Communication | 2 |
| Rely Control | 3 |
| LCD Screen | 4.3 inch |
| Breaker | 100A |
| Relay | 150A |
| Fuse | 160A |
| Precharge Relay | 50A |
| Precharge Resistance | 200W/100Ω |
| External DC input port | 24V |
| Dimensions | 577*485*150mm |
| Weight Approximate | 15.6kg |

3.4 Rack Module Specifications

| | |
|----------------------|----------------|
| Standard 19inch Rack | SR-Rack-13A |
| Dimensions | 776*552*2200mm |
| Weight Approximate | 57kg |

Installable 12 pcs batteries and 1 pcs High Voltage Battery cluster control box

3.5 Appearance Description


3.5.1 Battery system introduction



| Code | Name | Product Model |
|------|---------------------|---------------|
| A | PDU Module | SR-PDU100 |
| B | Battery Pack Module | SR-HOC05B |
| C | Rack | SR-Rack-13A |


Built in 1 control module and UP to 12 battery modules.

3.5.2 Battery Pack Module introduction



| No. | Name | Description |
|-----|----------|---|
| ① | B- | Battery module negative pole (black) |
| ② | B+ | Battery module positive pole (orange) |
| ③ | BCOM IN | Connection position of battery module communication and power supply input |
| ④ | BCOM OUT | Connection position of battery module communication and power supply output |


3.5.3 PDU Module introduction




| No. | Name | Description. | Position |
|-----|------------|--|----------|
| ① | B- | Connection position of the common negative pole of the battery (black). | Front |
| ② | B+ | Connection position of the common positive pole of the battery (orange). | Front |
| ③ | Air Switch | Used to manually control the connection between the battery rack and external devices. | Front |

| | | | |
|---|----------|--|-------|
| ④ | P-IN | Connection position with previous PDU communication. | Front |
| ⑤ | P-OUT | Connection position with next PDU communication. | Front |
| ⑥ | COM | BMS upgrade interface and connection PC interface. | Front |
| ⑦ | OUT | Communicative connection with the first battery module. | Front |
| ⑧ | PCS | PCS COM battery communication terminal: (RJ45 port) follow the CAN protocol (default baud rate: 500bps) and RS485 protocol (default baud rate:9.6bps), used to output battery information to the inverter. | Front |
| ⑨ | P- | Connection position of PCS negative pole (black). | Front |
| ⑩ | P+ | Connection position of PCS positive pole (orange). | Front |
| ⑪ | HMI | Display some important battery information. | Front |
| ⑫ | POWER ON | A start switch of 24VDC power inside the PDU. | Front |
| ⑬ | HV | High-voltage hazard indicator (yellow). | Front |
| ⑭ | ALARM | Battery system fault alarm indicator (red). | Front |
| ⑮ | POWER | Connection position of external 24VDC power supply. | Rear |
| ⑯ | WiFi | Antenna | Rear |

3.5.4 Rack Module introduction



| Code | Name |
|------|---------------|
| ① | Rack |
| ② | Fixed trestle |




| No. | Description. | PCS |
|-----|----------------------------|-----|
| ① | Side beam | 2 |
| ② | Right diagonal brace | 2 |
| ③ | Left diagonal brace | 1 |
| ④ | Rack fastener | 2 |
| ⑤ | M6*16screw | 40 |
| ⑥ | Beam | 4 |
| ⑦ | four-corner fixing fitting | 8 |

4 Application Scenarios

The lithium iron phosphate batteries with high performance and long service life are used in the energy storage module. Meanwhile, the modular structure design is adopted. Each energy storage module is internally integrated with the intelligent BMS system, which can be easily expanded and can be combined into 120kWh battery pack at most. This product is very suitable for industrial and commercial energy storage applications.

The battery storage can be combined with SRNE brand inverter to form an off-grid or hybrid photovoltaic system, which can solve the problem of electricity consumption in areas without electricity.



5 System Installation

5.1 Inspections before Installation



















Inspection of outer package

Before opening outer package of the energy storage, check if there is any visible damage on the outer package, such as holes, cracks or other signs of possible internal damage, and check the type of energy storage. If there is any abnormality on the package or model of the energy storage is inconsistent, do not open it and contact us as soon as possible.

Inspection of deliverables

After opening outer package of the energy storage, check if the deliverable is complete and whether there is any visible external damage. If any items are missing or damaged, please contact us.

5.2 Preparation of Tools and Meters

| Types | Tools and meters | | | |
|-------------------------------|---|---|--|---|
| Installation tool |  |  |  |  |
| |  |  |    |  |
| |  |  |  |  |
| Personal protective equipment |  |  |  |  |

5.3 Selection of Installation Location

5.3.1 Basic Requirements

- When the energy storage is running, the temperature of the case and the radiator will be high. Therefore, do not install them in a place that is easy to touch.

- Do not install in areas where flammable and explosive materials are stored.

- If the energy storage is installed in areas with salt damage, it will be corroded and may cause fire.

Therefore, do not install it outdoors in areas with salt damage. The areas with salt damage are defined as the areas which are not 500m away from shore or will be affected by sea breezes. The areas affected by the sea breezes vary depending on meteorological conditions (e.g. typhoons, monsoons) or topographical conditions (dams, hills).

- Do not install in the place where children can touch.

- The energy storage cannot be installed forwardly, horizontally, inversely, backwardly or sideways.

- When drilling holes on walls or ground, the goggles and protective gloves shall be worn.




- During drilling, the device should be shielded to prevent debris from falling into the device. After drilling, the debris shall be cleaned up in time.

- When handling any heavy objects, you should be prepared to bear loads to avoid being crushed or sprained.

- When handling the device by hand, wear protective gloves to avoid injury.

5.3.2 Installation Space Requirements

The battery system should be placed in the right position first, and the installation site should be smooth, and the wall should be solid, and the distance between the batteries should be greater than 200-350mm.




5.4 Device Installation

5.4.1 Installation of Rack


Step1:Frame Assembly

Use external hexagonal and internal cross combination screws and screwdrivers to connect the side beams with the top/bottom beams to form a rectangular frame. First assemble the top crossbeam, and then connect the bottom crossbeam, etc.



Step2:Diagonal Bracing Installation


Secure left/right diagonal braces on both sides of the beam structure using the same hexagon socket screw system.



Step3:Rack Positioning

Erect the completed rack vertically after assembly.

Wall Mounting: Attach rack fasteners to upper socket screw holes and secure to the wall using hexagon combination screws.




To avoid electrical shock or other injury, inspect existing electronic or plumbing installations before drilling holes.



Choose suitable firm wall with thickness greater than 80mm.


5.4.2 Installation of Battery and PDU

Install the battery from the bottom to the top, and make sure the battery is secured. When placing the battery, ensure that the battery is pushed to the bottom.



The battery pack is very heavy, which requires multiple people to install.

Fasten the battery with the accessory screws. Be careful that the battery falls down.



6 Electrical Connection










Before electrical connection, please ensure that the switches of the energy storage are in the "OFF" state. Otherwise, the high voltage of the device may cause electric shock.



The operations related to electrical connections must be carried out by professional electrical technicians. When carrying out electrical connections, the operator must wear personal protective articles.


6.1 Preparation of Cables

| No. | Cables | Description | Recommended specifications | Source |
|-----|------------------------|--|---|----------------|
| 1 | Battery Cable (red) | 75mm Power cord of battery module |  | Battery Module |
| 2 | Battery Signal line | Signal cable between battery |  | Battery Module |
| 3 | PDU Cable (red) | 65mm positive power cord of PUD |  | PDU Module |
| 4 | PDU Cable (black) | 3.2m negative power cord of PUD |  | PDU Module |
| 5 | PCS Cable (red) | 2m positive power cord to connect External PCS |  | PDU Module |
| 6 | PCS Cable (black) | 2m negative power cord to connect External PCS |  | PDU Module |
| 7 | PCS Signal line | 2m Connected to external inverter communication cable |  | PDU Module |

6.2 Electrical Connection

6.2.1 Connecting Grounding Wire


When installing equipment, the protective ground wire must be installed first; When removing the equipment, the protective ground wire must be removed finally.



6.2.2 Connecting Battery Power Cable

When connecting the battery wiring, please make sure that all switch is off and the indicator light is off. If the plug is connected properly, you will hear a "click" sound.

If you need to unplug the plug, you need to first turn off all devices and battery switches, and then wait for 5 minutes before proceeding, then press the self-locking clasp and unplug.




6.2.3 Connecting Battery Signal Line

The IN and OUT connections between battery packs use the battery communication cable.




6.2.4 Connecting PDU Power Cable

Connect the positive of the topmost battery to the positive of the PDU, and connect the negative of the bottommost battery to the negative of the PDU.





6.2.5 Connecting PDU Signal Line

Connect the PUD “OUT” interface to the battery “IN” interface.




6.2.6 Connecting PCS

6.2.6.1 Single Battery Cluster Connected To Inverter



6.2.6.2 Two Battery Clusters Connected To Inverter



7 System Debugging

7.1 Inspections Before Power-On

| No. | Inspection items | Acceptance criteria | Validation |
|-----|--|---|--|
| 1 | The energy storage is installed in place | The installation is correct, secure and reliable. | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| 2 | The installation environment meets requirements | The installation space is reasonable, and the environment is clean and tidy without any | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| 3 | The power cord is correctly connected | The positive and negative terminals are connected correctly without any missing. | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| 4 | The signal line is correctly connected | The signal line is connected reliably, and there is no wrong position | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| 5 | The grounding is reliable | The grounding wire is correctly and reliably connected. | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| 6 | The switch of the energy storage battery module is off | All switches connected to the energy storage are in the "OFF" state. | <input type="checkbox"/> Yes <input type="checkbox"/> No |

7.2 Power-On of Battery System


7.2.1 Power-up Sequence

After the battery is connected to the inverter, please power on in the following order.

Step1: Turn on DC Breaker

Step2: Press the Power on button and wait for the screen to light up.

Step3: Waiting for PDU self-test to complete, HV LED is turn on ,power on completed.



7.2.2 Shutdown Sequence

After disconnecting the inverter from the battery, please turn off the power in the following order.

Step1: Press the Power on button again and wait for the screen to go off.



Step2: Turn off DC Breaker

Step3: Wait for 5 minutes, power off completed.

7.2.3 System Status Indication

After the battery switch button is turned on, the LED indicator will light up or flash. The meaning of the LED indicator is as follows.



| LED | Colour | Appearance | Description |
|-------|--------|--|---|
| HV | yellow |  | The battery has started successfully and the high voltage output of the battery is normal |
| Alarm | red |  | System fault indication |

7.2.4 LCD Touch Screen


7.2.4.1 Main Page



| ID | Value |
|----|-------|
| ① | SOC |

| | |
|---|-----------------------|
| ② | Battery voltage |
| ③ | Battery current |
| ④ | Battery power |
| ⑤ | Discharge remain time |

7.2.4.2 Warning Page




| ID | Value |
|-----|--|
| ① | Cell Min and Max voltage |
| ② | Cell Min and Max temperature |
| HV | Over voltage Warning |
| LV | Over discharge Voltage Warning |
| HT | Over Temperature Warning |
| LT | Low Temperature Warning |
| OC | Overcurrent Warning |
| ISO | Insulation failure, there is a risk of current leakage |

7.2.4.3 Cell Voltage Page



| ID | Value |
|----|--------------|
| ① | Pack Number |
| ② | Cell Voltage |

7.2.4.4 Information Page



| ID | Value |
|----|--------------------------|
| ① | Request charging voltage |
| ② | Request charging current |
| ③ | Total charging capacity |
| ④ | Total working days |

| | |
|---|-------------------|
| ⑤ | LCD Turn off time |
| ⑥ | Reset WiFi |

If you can't connect to the network or need to change the network environment, please reset the WIFI.



7.4 WIFI Function


7.4.1 Download App

Scan the QR code to download the APP.




7.4.2 Register and Login

You need to register an account for the first time.





7.4.3 Add Device

Connecting the device requires turning on Bluetooth, WIFI, and location permissions.



7.4.4 Connect Network

Choose WIFI and enter the password, the device starts connecting to the network.



7.4.5 Reset WIFI

If you can't connect to the network or need to change the network environment, please reset the WIFI.



Only supports 2.4G band's WiFi , not supports 5G band's WiFi , please make sure that the 2.4G band of the router is turned on.

7.5 Bluetooth Function


7.5.1 Download App

Scan the QR code to download the APP.



7.5.2 Add Device

Connecting the device requires turning on Bluetooth, and location permissions.



7.6 Sleep Mode

If the battery is neither charged nor discharged, it will automatically enter sleep mode after a period of time. After entering sleep mode, BMS will turn off LCD and WiFi module to save power. If you want to continue using it, please turn the power button on and off again.

8 System Maintenance

8.1 System Power-Off



After the system is powered off, the case still has residual power and heat, which may cause electric shocks or burns. Therefore, protective gloves should be worn before operating the energy storage 5 minutes after the system is powered off. Maintenance operations on energy storage should be performed only after ensuring that all indicator lights of the energy storage are off.

Power-off operation steps of the system:

Step 1 Turn off the breaker switch between the inverter and AC output (If installed).

Step 2 Turn off the breaker switch between the inverter unit and AC input(If installed).

Step 3 Turn off the breaker switch between the inverter unit and the PV string(If installed).

Step 4 Turn off the breaker switch between the inverter and battery.

Step 5 Turn off button on storage battery modules, the energy storage is powered off successfully.

8.2 Routine Maintenance

To ensure the long-term and good operation of the energy storage system, it is recommended to perform the routine maintenance as described in this section.

| Items | Methods | Maintenance interval |
|--------------------------|---|--|
| System cleanliness | Check if the radiator is covered or dirt on a regular basis. | Once every six months to one year. |
| Running status of system | <ul style="list-style-type: none"> Observe whether the energy storage appearance is damaged or deformed. Listen to whether the energy storage has any abnormal sound during running. When the energy storage is running, check whether the indicator of the energy storage battery is correct. | Once every six months. |
| Electrical connection | <ul style="list-style-type: none"> Check if any cable connection is off or loose. Check if any cable is damaged, and especially if there are cuts on the sheath where the cable contacts with the metal surface. Check if the unused DC input terminals, energy storage terminals, COM ports, and covers are locked. | Half a year after first debugging and testing, and once every six months to one year thereafter. |
| Grounding reliability | Check if the grounding cable is grounded reliably. | Half a year after first debugging and testing, and once every six months to one year thereafter. |

8.3 Common Faults and Handling Methods

| Faults | Handling measures |
|---|---|
| The indicator light and LCD does not work | Check whether battery is sleeping mode.If the battery is neither charged nor discharged, it will automatically enter sleep mode after a period of time. |
| All indicators of the battery are off | If the battery power is low, you need to charge it before using it. If the battery is not used for a long time, it will automatically sleep, and it can be used normally after restarting. |
| Battery overcurrent protection fault | Check whether there is a short circuit in the battery wiring. Check whether the load power exceeds the maximum |
| The battery cannot be charged | Check if the battery is fully charged Check whether the ambient temperature is below -10 degrees. |
| Communication error with inverter | Check whether the communication interface is incorrectly plugged in and Whether the wiring is secure. Whether the battery address is set correctly. Whether the protocol is secure. |
| WIFI communication error | Check if the router settings are correct Check whether the routing network is normal Check whether the router's 2.4G frequency band is turned on |

8.4 Battery Storage and Maintenance

8.4.1 Battery Storage Requirements



Do not put the battery into fire. The battery may explode.

Do not open or damage the battery. The electrolyte flowing out from the battery is harmful to the skin and eyes. The electrolyte may also be toxic;

1. When being stored, the batteries shall be placed correctly in accordance with the marks on the packing case. Do not put them upside down or on the side.
2. When stacking up the battery packing cases, the stacking requirements on the outer package shall be met.
3. The batteries should be handled with care, and damage to batteries should be strictly prohibited.
4. Requirements for the storage environment:
 - Ambient temperature: -10°C to 55 °C, recommended storage temperature: 20°C to 30°C.
 - Relative humidity: 5%RH-80%RH.
 - Dry, well ventilated, and clean.
 - The corrosive organic solvents, gases and other substances shall be kept away.

- Exposing to direct sunlight shall be avoided.
- The distance from the heat source should not be less than two meters.

5. When being stored, the battery shall be disconnected from the external connection. If there is an indicator light on the battery panel, the indicator light shall be off.

6. When the stored batteries are going to be delivered, the first-in first-out principle should be followed.

7. After the battery is produced and tested, it shall be recharged to at least 50% SOC before being stored. If the device will not be used for a long period of time, discharge the battery to 45% to 60% of the battery capacity and disconnect the battery output to avoid the battery runs out;

8. Do not touch the battery pack with wet hands.□

9. Do not squeeze, drop, or pierce the battery.

10. The battery should always be disposed in accordance with local safety regulations.□

11. The battery should be stored and recharged in accordance with this User's Manual.

12. Do not reverse polarity of the battery when storing or transporting the batteries, the batteries shall not be stacked up without protective packaging, and the number of stacked packed batteries should not exceed the number specified on the packaging.

13. All operators of the energy storage system shall comply with the user manual, installation and service manual, and quality assurance requirements. Any damage to the device resulting from neglecting or misreading of the user's manual, installation and service manual, and the quality assurance requirements will invalidate the product warranty.

8.4.2 Requirements for Charging of Battery

The batteries to be stored for a long period of time (unused, for more than 3 months) must be kept in a dry and cool place. The storage voltage is 51V~53V. The batteries should be stored in a clean environment of $23 \pm 2^{\circ}\text{C}$ and humidity of 45%~75%. If the battery will be shelved and not used for a long period of time, it should be recharged every 3 months to ensure that the battery voltage is within the above range.

As for batteries and long-term storage, routine maintenance is required. Please charge the battery to 40% SOC at a current of 0.2C according to the requirements in the table below.

| Ambient temperature for storage | Relative humidity for storage environment | Storage Time | SOC |
|---------------------------------|---|--------------|-------------|
| <-10°C | / | Prohibited | / |
| -10~25°C | 5%~70% | ≤12 months | 30%≤SOC≤60% |
| 25~35°C | | ≤6 months | |
| 35~45°C | | ≤3 months | |
| >45°C | / | Prohibited | / |

8.5 Device Cleaning

It is recommended to clean and maintain the product from time to time. When cleaning, the dust and stains on the product shall be removed with a piece of soft dry cloth or vacuum cleaner. The product shall not be cleaned with organic solvents, corrosive liquids and other cleaning products.

8.6 Fault threshold and its response mode


| N0. | Fault name | Fault level | Trigger Value | delay | release value | delay | Discharge limiting | Discharge enable | Charge limiting | Charge enable | Action |
|-----|-------------------------|-------------|---------------|-------|---------------|-------|--------------------|------------------|-----------------|---------------|------------------------|
| 1 | Cell Low voltage | 1 | 2.9V | 2S | 3.1V | 2S | 0% | DIS | 100% | EN | SOC=0% |
| | | 2 | 2.7V | 2S | 2.9V | 2S | 0% | DIS | 100% | EN | Discharge relay is off |
| | | 3 | 2.5V | 2S | 2.6V | 2S | 0% | DIS | 100% | EN | All relay is off |
| | | 4 | 2.3V | 4min | / | / | / | / | / | / | Breaker is off |
| 2 | Cell over voltage | 1 | 3.6V | 2S | 3.34V | 2S | 100% | EN | 0% | DIS | SOC=100% |
| | | 2 | 3.65V | 2S | 3.34V | 2S | 100% | EN | 0% | DIS | Charge relay is off |
| | | 3 | 3.7V | 2S | Manual | / | 100% | EN | 0% | DIS | All relay is off |
| | | 4 | 3.8V | 1S | / | / | / | / | / | / | Breaker is off |
| 3 | Cell voltage difference | 1 | / | / | / | / | / | / | / | / | / |
| | | 2 | 500mV | 2S | 250mV | 2S | 50% | EN | 50% | EN | / |
| | | 3 | / | / | / | / | / | / | / | / | / |
| | | 4 | / | / | / | / | / | / | / | / | / |
| 4 | Pack voltage difference | 1 | / | / | / | / | / | / | / | / | / |
| | | 2 | / | / | / | / | / | / | / | / | / |
| | | 3 | 15V | 10S | Manual | / | 0% | DIS | 0% | DIS | All relay is off |
| | | 4 | | | | | | | | | |
| 5 | Cell over temperature | 1 | 55°C | 2S | 50°C | 2S | 100% | EN | 100% | EN | / |
| | | 2 | 61°C | 2S | 56°C | 2S | 0% | DIS | 0% | DIS | / |
| | | 3 | 63°C | 2S | 40°C | 2S | 0% | DIS | 0% | DIS | All relay is off |


| | | | | | | | | | | | |
|----|--------------------------|---|--------------------------|------|---------|-----|------|-----|------|-----|------------------|
| | | 4 | / | / | / | / | / | / | / | / | / |
| 6 | Cell Low temperature | 1 | -11°C | 2S | -5°C | 2S | 100% | EN | 0% | DIS | / |
| | | 2 | -21°C | 2S | -10°C | 2S | 0% | DIS | 0% | DIS | / |
| | | 3 | -31°C | 2S | -20°C | 2S | 0% | DIS | 0% | DIS | All relay is off |
| | | 4 | / | / | / | / | / | / | / | / | / |
| 7 | Temperature difference | 1 | 15°C | 2S | 10°C | 2S | 50% | EN | 50% | EN | / |
| | | 2 | 25°C | 2S | 20°C | 2S | 20% | EN | 20% | EN | / |
| | | 3 | / | / | / | / | / | / | / | / | / |
| | | 4 | / | / | / | / | / | / | / | / | / |
| 8 | Over discharge current | 1 | 60A | 300S | 50A | 30S | 100% | EN | 100% | EN | / |
| | | 2 | 100A | 180S | 60A | 30S | 0% | DIS | 100% | EN | / |
| | | 3 | 120A | 60S | 60A | 30S | 0% | DIS | 100% | EN | All relay is off |
| | | 4 | / | / | / | / | / | / | / | / | / |
| 9 | Over charge current | 1 | 60A | 60S | 50A | 30S | 100% | EN | 50% | EN | / |
| | | 2 | 70A | 10S | 60A | 30S | 100% | EN | 0% | DIS | / |
| | | 3 | 80A | 5S | 60A | 30S | 100% | EN | 0% | DIS | All relay is off |
| | | 4 | / | / | / | / | / | / | / | / | / |
| 10 | Relay Fault | 1 | / | / | / | / | / | / | / | / | / |
| | | 2 | / | / | / | / | / | / | / | / | / |
| | | 3 | Relay adhesion fault | 1S | / | / | 0% | DIS | 0% | DIS | All relay is off |
| | | 4 | Relay open circuit fault | 1S | / | / | 0% | DIS | 0% | DIS | All relay is off |
| 11 | Insulation leakage fault | 1 | 500Ω/V | 3S | 1000Ω/V | 3S | 100% | EN | 100% | EN | / |
| | | 2 | 300Ω/V | 3S | 500Ω/V | 3S | 100% | EN | 100% | EN | / |
| | | 3 | 100Ω/V | 3S | Manual | / | 0% | DIS | 0% | DIS | All relay is off |
| | | 4 | / | / | / | / | / | / | / | / | / |

9 Product Dimensions and Packaging

9.1 Product Dimensions


The external dimensions of the energy storage battery module ,






9.2 Package Dimensions


A、 PDU , The packaging size of SR-PDU100 is 630*590*230mm.











B、 single energy storage battery module , The packaging size of SR-HOC05B is 670*590*220mm.











C、 Rack , The packaging size of SR-Rack-13A is 2292*660*197mm.



9.3 Accessories

| SR-PDU100 | | | | |
|-----------|---|---|----------|---------------|
| NO. | Picture | materials | Quantity | Remark |
| 1 |  | High-voltage control box 850V/100A | 1 | 577*485*150mm |
| 2 |  | 65mm positive power cord of PUD | 1 | 65mm |
| 3 |  | 3.2m negative power cord of PUD | 1 | 3.2m |
| 4 |  | 2m positive power cord to connect External PCS | 1 | 2m |
| 5 |  | 2m negative power cord to connect External PCS | 1 | 2m |
| 6 |  | 2m Connected to external inverter communication cable | 1 | 2m |
| 7 |  | Screw/Wrie | 4 | M6*16 |
| 8 |  | User Manual | 1 | Standard |

| SR-HOC05B | | | | |
|-----------|---|---|----------|---------------|
| NO. | Picture | materials | Quantity | Remark |
| 1 |  | Energy storage battery module 51.2V/50A | 1 | 603*485*140mm |
| 2 |  | 75mm Power cord of battery module | 1 | 65mm |
| 3 |  | Signal cable between battery | 1 | 3.2m |
| 4 |  | Screw/Wrie | 4 | M6*16 |

| SR-Rack-13A | | | | |
|-------------|---|----------------------|----------|----------------------|
| NO. | Picture | materials | Quantity | Remark |
| 1 |  | Rack | 1 | 776*552*2200mm |
| 2 |  | Side fastener | 2 | 150*60*50mm |
| 3 |  | Screw/Wrie | 40 | M6*16 |
| 4 |  | Mounting Frame Screw | 2 | M8*60 expansion bolt |