

# **User Manual**



# Solar Hybrid Inverter

HESP48140UH3 | HESP48160UH3 | HESP48180UH3

Ver: V01 2025-08-26

# **Contents**

1.	Safety Precautions	3
	1.1 How to Use This Instruction Manual	3
	1.2 Safety signs	3
	1.3 Safety Instructions	3
2.	Product Introduction	4
	2.1 Product Description	4
	2.2 Product Features	
	2.3 System Connection Diagram	
	2.4 Product Overview	
	2.5 Product Size	
3.	Installation	
	3.1 Part List	
	3.2 Installation Instructions	
4.	Connection Instructions	
	4.1 Single-Phase or Three-Phase Mode	
	4.2 Cable & Circuit Breaker Selection	
	4.3 AC Input, Output, and Generator Connection	
	4.4 Battery Connection	
	4.5 PV Connection	
	4.6 Dry Contact Connection	
	4.7 Grounding Connection	
	4.8 Final Installation	
	4.9 Parallel Connection	
5.	Operation	
-	5.1 Operation and Display Panel	
	5.2 Setting Parameters	
	5.3 Time-slot Charging/Discharging Function	
	5.4 Battery Parameters	
6	Communication	
٠.	6.1 Product Overview	
	6.2 USB-1 Port	
	6.3 WIFI Communication Function	
	6.4 RS485 Port	
	6.5 CAN Port	
	6.6 Display Port USB-2	
	6.7 DRM(Only Australia)	
	6.8 External CT Prot	
	6.9 DIP Switch Configuration	
	6.10 Dry Contact Function	
7	Fault and Remedy	
•	7.1 Fault Codes	
	7.2 Troubleshooting	
Ω	Protection and Maintenance	
u.	8.1 Protection Functions	
	8.2 Maintenance	
a	Datasheet	
		7.7



# 1. Safety Precautions


# 1.1 How to Use This Instruction Manual

This manual contains important information, guidelines, operation and maintenance for the following products:

HESP Series: 48140UH3, 48160UH3, 48180UH3.

Read the manual and other related documents before performing any operation on the inverter. Documents must be stored carefully and be available at all times.

# 1.2 Safety signs



# 1.3 Safety Instructions

**WARNING:** This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

- Be sure to comply the local requirements and regulation to install this inverter.
- Beware of high voltage. Please turn off the switch of each power sources before and during the installation to avoid electric shock.
- For optimum operation of this inverter, please follow required specification to select appropriate cable size and necessary protective device.
- Do not connect or disconnect any connections when the inverter is working.
- Do not open the terminal cover when the inverter working.
- Make sure the inverter is well grounding.
- Never cause AC output and DC input short circuited.
- Do not disassembly this unit, for all repair and maintenance, please take it to the professional service center.
- Never charge a frozen battery.




# 2. Product Introduction

# 2.1 Product Description

The HESP48XXXUH3 series is a new type of solar energy storage inverter that integrates solar energy storage, utility charging, energy storage, and AC sine wave output.

It is highly compatible with various application scenarios, including residential energy storage systems.

It adopts DSP control and achieves high response speed, reliability, and compliance with an industrial standard through an advanced control algorithm. It provides users with a reliable and efficient energy conversion solution.



# 2.2 Product Features

- Supports lead-acid battery and li-ion battery connections.
- Smart load function.
- AC coupling function.
- With a dual activation function when the li-ion battery is dormant; either mains or photovoltaic power supply access can trigger the activation of the li-ion battery.
- Support three-phase pure sine wave output.
- 100% unbalanced output, with each phase output power reaching over 50% of the rated power.
- Supports phase voltage adjustment in the range of 100, 105, 110, 115, 120, 127Vac.
- Supports three PV inputs, with the function of simultaneously tracking the maximum power charging or carrying capacity of three MPPT.
- Three-channel MPPT, efficiency up to 99.9%, single maximum current of 40A, perfectly adapted to high-power modules.
- With time-slot charging and discharging setting function, it helps users to take



advantage of peak and valley tariffs and save electricity costs.

- Energy-saving mode function to reduce no-load energy losses.
- With two output modes of utility bypass and inverter output, with uninterrupted power supply function.
- LCD large screen dynamic flow diagram design, easy to understand the system data and operation status.
- Multi-functional protection logic, including short-circuit protection, overcurrent protection, overvoltage protection, undervoltage protection, overload protection, and over-temperature protection.
- Support CAN, USB, and RS485 communication.


# 2.3 System Connection Diagram


The diagram below shows the system application scenario of this product. A complete system consists of the following components:

- PV Modules: Converts light energy into DC energy, which can be used to charge the battery via an inverter or directly inverted into AC power to supply the load.
- Grid: Connected to the mains AC input, supplying power to loads while charging batteries. The system can operate off-grid when batteries and PV modules power the loads.
- Battery: The role of the battery is to ensure the normal power supply of the system loads in case of insufficient photovoltaic and no utility power.
- Home Load: Connects to a variety of home and office loads including refrigerators, lamps, TVs, fans, air conditioners and other AC loads.
- Generator/Secondary Load/Micro-Inverter Input: When connected to an AC generator, supplies power to loads and charges batteries simultaneously. Without generator connection, this interface can be configured as a secondary load output to power loads. When connected to micro-inverters, it supplies power to loads and charges batteries concurrently.
- **Inverter:** It is the energy conversion device of the whole system.




# Note: The actual application scenario determines the specific system cabling.








# **2.4 Product Overview**







1	LED Indicator Light	2	LCD Screen	3	Physical Button
4	Load Output	5	Grid Input	6	N Line Terminal
7	PE Terminal	8	Battery Circuit Breaker	9	Grid CT1
10	Micro-inverter CT2	11	DRM Port	12	485/Meter Port
13	485/WiFi Port	14	485/EMS Port	15	Display USB-2
16	USB-1 Port	17	Dry Contact Interface SC1	18	CAN Communication Port
19	Parallel Port-B	20	Parallel Port-A	21	CAN/BMS2 Communication Port
22	CAN/485/BMS1 Communication Port	23	PV Input	24	Generator Input
25	WiFi Antenna	26	PV DC Circuit Breaker	27	Start Switch
28	WiFi Module				



# 2.5 Product Size









# 3. Installation

# 3.1 Part List


Please check the equipment before installation. Make sure that there is no damage to the packaging. You should have received the following items in the package:









Hex Key\_L-Type\_5mm/ Hex Key\_L-Type\_8mm x 1pcs



Expansion screws M8×60mm x 5pcs




Spare screw M6x18mm x 1pcs




Hex socket head triple-combination screws M6x16 x 2pcs








Parallel connection cable x 1pcs




CT x 1pcs




WIFI module x 1pcs


x 4pcs



Three-phase meter (Optional) x 1pcs









Quality certificate x 1pcs



Outgoing inspection report / Warranty Card x 1pcs / x 1pcs




## 3.2 Installation Instructions

### 3.2.1 Installation Location Selection

The HESP48XXXUH3 series can be used outdoors (protection class IP65). Please consider the followings before selecting the location:

- Choose the solid wall to install the inverter.
- Mount the inverter at eye level.
- Adequate heat dissipation space must be provided for the inverter. (specific requirements: the heat dissipation distance above and below the inverter should be ≥ 200mm, and the distance on both left and right sides should be ≥500mm).
- The ambient temperature should be between-25~60°C (-13~140°F) to ensure optimal operation.



# 

- Do not install the inverter where highly flammable materials are near by.
- Do not install the inverter in potential explosive areas.
- Do not install the inverter with lead-acid batteries in a confined space.


# AUTION

- Do not install the inverter in direct sunlight.
- Do not install or use the inverter in a humid environment.



# 3.2.2 Mounting the Inverter

- **Step 1:** Determine the positions for drilling holes, ensure the position of holes are level, then mark them with a marker pen, use the hammer drill to drill holes on the wall. Keep the hammer drill perpendicular to the wall, do not shake when drilling, so as not to damage the wall. If the error of the hole is too big, you need to reposition.
- **Step2:** Insert M8\*60 expansion bolt vertically into the hole and pay attention to the insertion depth of the expanding bolt(should be deep enough)
- **Step3:** Align the wall hanger with the position of holes, fix the wall hanger on the wall by tightening the expansion bolt with nuts.
- **Step 4:** Align the mounting holes and attach the inverter to the wall bracket, securing it in place with safety screws.







# 3.2.3 Removing the Terminal Protection Cover

Use the key to unlock the tower latch, and the protective cover will open.

Removable fan cover for cleaning







!\ NOTICE

When using the device in areas with poor air quality, the dust screen is easily blocked by air particles. Please disassemble and clean the dust screen periodically to avoid affecting the internal air flow rate of the inverter, which may trigger an over-temperature protection fault (19/20 fault) affecting the use of the power supply and the service life of the inverter.

# 4. Connection Instructions

# 4.1 Single-Phase or Three-Phase Mode





Three phase output

Items	Description
Applicable model	HESP series UH3 model
AC output phase voltage (L-N)	90~140Vac, 120Vac default
AC output phase voltage (L-L)	156~243Vac, 208Vac default



NOTICE

- Users can change the output voltage through the settings menu. For details, refer to Chapter 5.2.
- The output voltage corresponds to the parameter setting item 【Operating Mode】 【Output Phase Voltage】, and the output phase voltage can be set within the range of 100V to 127V.

# 4.2 Cable & Circuit Breaker Selection

## **■ PV Input**

Models	Cable Diameter	Max. Input Current	Circuit Breaker Specifications
HESP48140UH3	6mm²/ 10 AWG	40A	2P-50A
HESP48160UH3	6mm²/ 10 AWG	40A	2P-50A
HESP48180UH3	6mm²/ 10 AWG	40A	2P-50A

### Battery

Models	Cable Diameter	Max. Input Current	<b>Circuit Breaker Specifications</b>
HESP48140UH3	70mm²/ 00 AWG	130*2A	2P-200A
HESP48160UH3	70mm²/ 00 AWG	150*2A	2P-200A
HESP48180UH3	70mm²/ 00 AWG	165*2A	2P-200A

### ■ Grid

Models	Output Mode	Cable Diameter	Max. Input Current	Circuit Breaker Specifications
HESP48140UH3	Three-phase	85mm <sup>2</sup> /000AWG(L1/L2/L3/N)	200A	4P-250A
HESP48160UH3	Three-phase	85mm <sup>2</sup> /000AWG(L1/L2/L3/N)	200A	4P-250A
HESP48180UH3	Three-phase	85mm <sup>2</sup> /000AWG(L1/L2/L3/N)	200A	4P-250A


#### Generator

Models	Output Mode	Cable Diameter	Max. Input Current	Circuit Breaker Specifications
HESP48140UH3	Three-phase	30mm²/3AWG(L1/L2/L3/N)	75A	4P-100A
HESP48160UH3	Three-phase	30mm <sup>2</sup> /3AWG(L1/L2/L3/N)	75A	4P-100A
HESP48180UH3	Three-phase	30mm <sup>2</sup> /3AWG(L1/L2/L3/N)	75A	4P-100A



#### Load


Models	Output Mode	Cable Diameter	Max. Output Current	Circuit Breaker Specifications
HESP48140UH3	Three-phase	30mm <sup>2</sup> /3AWG(L1/L2/L3/N)	200A	4P-250A
HESP48160UH3	Three-phase	30mm <sup>2</sup> /3AWG(L1/L2/L3/N)	200A	4P-250A
HESP48180UH3	Three-phase	21mm²/6AWG(L1/L2/L3/N)	200A	4P-250A





# 4.3 AC Input, Output, and Generator Connection

Connect the live, neutral and ground cables in the position and order of the cables as shown in the diagram below.






## ! DANGER

- Before connecting AC input and output, the circuit breaker must be turned off to avoid electric shock hazards, and never operate with electricity.
- Please check that the cable used is sufficient for the requirements, too thin, poor quality cables are a serious safety hazard.

# 4.4 Battery Connection

Connect the positive and negative cable of the battery according to the diagram below.




## ! DANGER

- Before connecting the battery, the circuit breaker must be turned off to avoid electric shock hazards, and never operate with electricity.
- Confirm the positive and negative poles of the battery according to the markings to ensure correct connection, avoiding inverter damage caused by reverse polarity.
- Verify the cable specifications and parameters, and select cables that meet the rated current and voltage transmission requirements of the equipment. Cables with too small diameter or substandard insulation shall be forbidden.
- The connection cables from the two battery sets to the inverter should be kept as consistent in length as possible to avoid uneven current distribution caused by line impedance differences, which may affect the overall system performance.



## 4.5 PV Connection

Connect the positive and negative cables of the three PV circuits according to the diagram below.



## A DANGER

- Before connecting the PV, the circuit breaker must be turned off to avoid electric shock hazards, and never operate with electricity.
- Make sure that the open-circuit voltage of the PV modules connected in series doesnot exceed the max. open-circuit voltage of the inverter (the value is 600V), otherwise the inverter may be damaged.

# **Transmitter-PLC Device(Customer Optional)**

The APsmart Rapid Shutdown System Transmitter-PLC is part of a rapid shutdown solution when paired with APsmart RSD-D, a PV module rapid shutdown unit. While powered on, the Transmitter-PLC sends a signal to the RSD-D units to keep their PV modules connected and supplying energy. RSD-D units automatically enter rapid shutdown mode when the Transmitter-PLC is switched off and resume energy production when power is restored to the Transmitter-PLC






# 4.6 Dry Contact Connection


Use a small screwdriver to push backward in the direction of the arrow, and insert the communication cable into the dry contact port.

Communication cable diameter: 0.2~1.5mm<sup>2</sup>



# **4.7 Grounding Connection**

Please make sure the grounding terminal connect to the Grounding Bar.



NOTICE

Grounding wire shall be not less than 4 mm<sup>2</sup> in diameter and as close as possible to the earthing point.



## 4.8 Final Installation

After ensuring that the wiring is reliable and the wire sequence is correct, restore the terminal protection cover to its original position.

- **Step 1:** Close the circuit breaker of the battery.
- **Step 2:** Press the ON/OFF switch on the side of the inverter. The screen and indicator lights turning on indicates that the inverter has been activated.
- Step 3: Sequential close of the circuit breakers for PV, AC input and AC output.
- **Step 4:** Start the loads one by one in order of power from small to large.

## 4.9 Parallel Connection

# 4.9.1 Parallel Operation

- 1. Up to 9 units connected in parallel.
- 2. When using the parallel operation function, the following connecting lines (package accessories) shall be firmly and reliably connected.





#### 1.Photovoltaic connection:

When connecting in parallel, the PV arrays connected to each inverter must be independent of each other. The PV arrays corresponding to PV1, PV2, and PV3 ports of the same inverter must also be independent.

## 2.Battery connection:

In parallel operations, all solar energy storage inverters must be connected to the same battery bank. Connect BAT+ to BAT+ and BAT- to BAT-. Before powering on the system, thoroughly check the wiring configuration to ensure correctness. Confirm that the wiring lengths between each inverter and the battery are consistent, and verify that the cable size meets the system's current transmission requirements. Incorrect connections may cause abnormal operation of the parallel system.

#### 3.Load connection:

In three-phase parallel connections, all solar energy storage inverters must be connected with N to N and PE to PE. The AC output L lines of the same phase should be connected together. The wiring method is the same when using a generator as a secondary load.



#### 4. Grid connection:

In three-phase parallel connections, all solar energy storage inverters must be connected with N to N and PE to PE. The grid L lines of the same phase should be connected together. The wiring method is identical when using a generator as an input source or for micro-inverters.

#### 5. Communication Lines:


Our parallel communication cable is a shielded 8-pin network cable suitable for both single-phase and three-phase parallel connections. Each unit must have one input and one output connection. In a parallel system, the "Parallel A" interface of this machine must be connected to the "Parallel B" interface of the target machine. It is strictly prohibited to connect the "Parallel A" interface of this machine to either the "Parallel B" interface of the same machine or the "Parallel A" interface of the target machine. Additionally, secure each unit's parallel communication cable firmly to the 8-pin network connector to prevent disconnections or poor contacts, which may lead to abnormal system operation or damage to the output.

**6**.Before and after connecting the system, carefully refer to the system wiring diagram below. Ensure all connections are correct and secure before powering on.

**7.**After the system is correctly wired, powered on, and operating normally, if a new inverter needs to be connected, ensure that the battery input, PV input, AC input, and AC output are disconnected, and all solar energy storage inverters are powered off before reconnecting to the system.


# 4.9.3 Schematic Diagram for Three-Phase Parallel Connection Guidance

Set the parallel mode of each inverter to "Parallel".






## a) Two units connected in parallel:



# b) Three units connected in parallel:






# 5. Operation

# **5.1 Operation and Display Panel**

The inverter's operation and display panel includes 1 LCD screen, 3 LED indicators, and 4 physical buttons.



# Physical buttons

Button	Description
	To enter/exit the setting menu
	To last selection
	To next selection
$\bigcirc$	To confirm/enter the selection in setting menu

### **■ LED indicators**

Indicator	Color	Description
FAULT	Red	Flashing: Error occurred, Primary Fault Continued: Error occurred, Secondary Fault
CHARCE	Croon	Continued: Charging completed
CHARGE Green		Flashing: Charging in progress
A.C. (TNI) /	Vallani	Continued: Utility grid bypass output
AC/INV	Yellow	Flashing: Inverter output



## Display Panel



Icon	Description	Icon	Description
-~	Microinverter	盘	Grid
	Solar Panel	90	Generator
Ē	Battery	<b>~</b>	UPS Load
命	Household Load	INVERTER	Inverter
lack	Home Page	0	Energy Saving Mode
C	Historical Data	<b>\Q</b>	Settings
01:05	Local Time	<b>4</b> »	Buzzer
(i-	WiFi Status	0 0	Energy Flow
MASTER	Main Unit Logo		

#### ■ View real-time data

On the LCD home screen, click the inverter icon, battery icon, utility grid icon, generator icon, UPS load icon, or PV icon allows viewing of real-time data for each component. The microinverter and household load icons are non-clickable, as their data is fully displayed on the home page.

System Data				
NO.	Real-Time Data Item	NO.	Real-Time Data Item	
1	MCU1 Version	11	SN Code (Inverter Serial Number)	
2	MCU2 Version	12	Machine Status	
3	Minor Version Number	13	DC/DC Temperature	




4	LCD Version	14	DC/AC Temperature			
5	Rated Power	15	Transformer Temperature			
6	Customer ID	16	External Battery Temperature			
7	RS485 Address	17	Parallel Total Local Load Power			
8	Bus Positive Voltage	18	Parallel Total Household Load Power			
9	Bus Negative Voltage	19	Parallel Total Grid Power			
10	Bus Total Voltage	20	Parallel Total Generator Power			
	Battery Data					
1	Battery 1 Voltage	7	Battery 2 Voltage			
2	Battery 1 Charge/Discharge Power	8	Battery 2 Charge/Discharge Power			
3	Battery 1 Charge/Discharge Current	9	Battery 2 Charge/Discharge Current			
4	Battery 1 SOC (%)	10	Battery 2 SOC (%)			
5	Battery Type	11	BMS Communication Protocol			
6	Charging Status	12	BMS Data			
	Grid	Data				
1	L1 Voltage	8	L2 Voltage			
2	L1 Current	9	L2 Current			
3	L1 Active Power	10	L2 Active Power			
4	L1 Apparent Power	11	L2 Apparent Power			
5	L3 Voltage	12	L3 Active Power			
6	L3 Current	13	L3 Apparent Power			
7	Frequency	14	Utility Charging Current			
	UPS L	oad Data				
1	L1 Voltage	10	L2 Voltage			
2	L1 Current	11	L2 Current			
3	L1 Active Power	12	L2 Active Power			
4	L1 Apparent Power	13	L2 Apparent Power			
5	L3 Voltage	14	L3 Apparent Power			
6	L3 Current	15	L3 Active Power			
7	L1 Load Rate	16	L2 Load Rate			
8	L3 Load Rate	17	Frequency			
9	Overall Load Rate					
	PV Panel Data					
1	Solar1 Voltage V	6	Solar2 Power W			
2	Solar1 Current A	7	Solar3 Voltage V			



3	Solar1 Power W	8	Solar3 Current A			
4	Solar2 Voltage V	9	Solar3 Power W			
5	Solar2 Current A	10	PV Total Power			
	Generator Data					
1	L1 Voltage	8	L2 Voltage			
2	L1 Current	9	L2 Current			
3	L1 Active Power	10	L2 Active Power			
4	L1 Apparent Power	11	L2 Apparent Power			
5	L3 Voltage	12	L3 Active Power			
6	L3 Current	13	L3 Apparent Power			
7	Frequency	14	Charging Current			
	Home Lo	oad Data				
1	L1 Voltage	8	L3 Apparent Power			
2	L1 Current	9	L2 Voltage			
3	L1 Active Power	10	L2 Current			
4	L1 Apparent Power	11	L2 Active Power			
5	L3 Voltage	12	L2 Apparent Power			
6	L3 Current	13	Frequency			
7	L3 Active Power					

## Browsing Detailed Data with Buttons

1. Press the up/down buttons, and when "HOME" is highlighted in blue, press the confirm button to select the home page icon.






2. After selecting the home page icon, press the confirm button again to enter the data details page.



# **5.2 Setting Parameters**

### **Operation Instructions:**


- 1.Click the "Settings" button in the bottom menu bar of the screen to enter the settings interface. It includes seven categories: "Basic Settings", "Operation Mode Settings", "Battery Settings", "Grid Settings", "Advanced Settings", "WIFI Firmware Settings", and "Firmware Upgrade".
- 2. When modifying settings, if password permission is enabled, a password must be entered to modify the parameters.






# 5.2.1 Basic Settings

# 5.2.1.1 Display Setting



- Language: English, Italian, German, Spanish, Chinese.
- RS485 Address: RS485 address of the inverter.
  - ① Single device: Adjustable range 1~254.
  - 2 Parallel devices: Adjustable range 1~9.
- Date: Set year, month, day.
- Time: Set hour and minute.
- Screen-On Time(Min.): Adjustable range 1~30 minutes.
- Screen always On: Select whether the screen stays on continuously.
- Beep: Select whether to enable buzzer alarm.
- Backlight brightness: Adjustable from 0~100%.
- Restart LCD: Restart the Screen


## **5.2.1.2 Password Setting(Change Password)**



- New Password: Enter a custom new password.
- Confirm Password: Re-enter exactly the same content as the new password above to verify the accuracy of the password setting.

# 5.2.2 Operation Mode Settings

# 5.2.2.1 Working Mode



- 1. Grid power sales: on grid output power.
- **2. UPS Load:** Connected to the LOAD port of the machine.
- **3. Home Load:** Refers to the load connected to the machine's GRID port, which requires external CT or energy meter for use.(Otherwise, the power of the Home load cannot be detected.)
- **4. AC Coupling:** Connect the grid-connected inverter to the grid side of the hybrid inverter.




This is the detailed page of "Working Mode"					
Parameter Meaning	Options	Description			
	On grid	Direct grid connection of excess PV energy.			
	Limit power to UPS load	In this mode, solar or battery energy is only used for UPS load and smart load,Excess energy will not be fed into the grid (UPS load is reverse-flow protected).			
Hybrid grid mode	Limit power to home load	In this mode, solar or battery energy is used only for the UPS load, smart load, and home load. Excess energy will not be fed into the grid (HOME load is reverse-flow protected).			
Tiyona gira mode	AC Coupling	This mode is used to add AC coupling functionality to ongrid inverters.  The on-grid inverter needs to be connected to the grid side of the hybrid inverter (effective only when the GEN port is not set to micro-inverter mode); or connected to the generator side of the hybrid inverter (effective only when the GEN port is set to micro-inverter mode).  In this mode, the hybrid inverter will use the grid energy from the on-grid inverter to power loads or charge batteries.			
PV/Microinverter energy manage	CT1 is not connect (effective only whe subsequent loads) When the hybrid g CT1 is successfully (effective only whe subsequent loads) First to Load  First to charging	rid mode is set to "Limit power supply to UPS load" or when ed, the meter is not communicating, or communication fails in the meter detection location is set to the grid side), the refer to the UPS load and smart load.  In id mode is set to "Limit Home Load/Grid Power Supply" and connected or the meter communication is successful in the meter detection location is set to the grid side), the refer to the UPS load, smart load, and home load.  PV energy priority: load>charge>on grid.  Micro-inverter energy priority: load>charge>on grid.  PV energy priority: charge>load>on grid.  Micro-inverter energy priority: load>charge>on grid.  PV energy priority: load>charge>on grid.			
	First to grid	Micro-inverter energy priority: load>on grid>charge.			
	Standby	Battery only discharge in off-grid working mode.			
Battery energy manage	Battery to UPS load	The battery can supply power to the UPS load, smart load, and home load, but does not participate in selling power to the grid.			
battery energy manage	Battery to home load	The battery powers UPS loads, smart loads, and household loads, but does not participate in grid selling.			
	Battery to grid sell	The battery can supply power to the UPS load, smart load, and home load, and participate in selling power to the grid.			
Parallel mode	Stand-alone.				
i aranei illoue	Parallel operation.				
Grid type	Three-Phase Three	-Wire System.			
Grid type	Three-Phase Four-Wire System.				
Output phase voltage	Settable: 100V,105V,110V,115V,120V , 127V				



## 5.2.2.2 Peak Shaving






- Timed charging enable: Select whether to enable scheduled charging.
- Timed discharging enable: Select whether to enable scheduled discharging.
- Start/End Time: Set the time period for scheduled charging/discharging.
- Stop SOC: Set the battery's cutoff SOC values for charging/discharging during the scheduled charging/discharging time periods. (effective when BMS communication is successful).
- Stop Volt: Set the battery's cutoff voltage values for charging /discharging during the scheduled charging/ discharging time periods. (effective when BMS communication is not established or fails).
- Max. Power: Setting the battery charging power and discharging power during the scheduled charging and discharging time period.
- Grid: Allow the grid to charge the battery during the scheduled charging period.
- Gen: Allow the generator to charge the battery during the scheduled charging period.
- Max. consumption enable: Allow the battery to discharge outside the scheduled discharging period.
- Weekly Enable: Set the days of the week for scheduled charging/discharging (only valid for scheduled charging/discharging).



# 5.2.3 Battery Settings

## 5.2.3.1 Battery Type



- BMS comm. interface:
  - ① **Disable:** BMS communication disabled.
  - ② RS485: BMS RS485 communication.
  - ③ CAN: BMS CAN communication.
- Battery Type:
  - ① **USER define:** All battery parameters can be customized by the user.
  - ② SLd: Sealed Lead-acid Battery.
  - ③ **FLd:** Flooded Lead-acid Battery.
  - 4 **GEL:** Gel Lead-acid Battery.
  - **5** No battery: No battery connected.
- ⑥ **LFP/14/ 15/LFP 16:** Li-FePO₄ /14/15/16, corresponding to 14-series, 15-series, and 16-series Li-FePO₄ batteries.
- N13/ N14: NCM Lithium Battery N13/N14, corresponding to 13-series and
   14-series NCM lithium batteries.
- BMS comm. protocol: When the BMS port selection item is set to RS485 or CAN, the corresponding lithium battery manufacturer brand shall be selected for communication:
  - ① 485 protocol:

PACE=PACEEX	RUDA=RADAR	AOGUAN=AUTOONE	OULITE=OLITER	CEF=CFGE
XINWANGDA	XiongTao	DAQIN=Dyness	WOW=SRNE	PYL=Pylontech
MIT=FOX ESS	XIX=Xinyi energy	POL=PowMr	GUOX=GOTION	SMK=SMK POWER
VOL=VILION	WES	SGP	GSL	PYT=Pylon tech 2

#### ② CAN protocol:


UZE=UZENERGY	PYL=Pylontech	Victro	DEY	HONGHE
WOW=SRNE	SGP=SGP	GSL=GSL energy	PYL=Pylontech	RUIXU
RENAC	DUNEXT	General	LUX/LuxPower	

Note: Please refer to the actual display on the screen.

- Battery chg. curr. limit mode(valid for BMS communication):
  - ① **HMI setting:** The maximum battery charging current is limited by the charging current setting value of the inverter.
  - ② **BMS setting:** The maximum battery charging current is restricted by the current limit value of the RMS
  - ③ **Inverter setting:** The maximum battery charging current is limited by the derating logic of the device.
- Batt. Chg Temp Compensation: Used to select whether to enable temperature compensation.



## 5.2.3.2 Battery Charging




- Grid charging enable: Select whether to allow the grid to charge the battery (not applicable to scheduled charging).
- Generator charging enable: Select whether to allow the generator to charge the battery (not applicable to timed charging).
- Max. chg. voltage: Set the maximum charging voltage during constant voltage charging of the battery.
- Batt. Recharging voltage: After the battery is fully charged, the inverter stops charging. Charging
  resumes when the battery voltage drops below this value. (This setting is effective when BMS
  communication is not established or has failed.)
- Batt. SOC stop chg.: When the SOC reaches the specified value, battery stops charging. (Valid when BMS communication is normal).
- Max. chg. curr. by Grid: Set the maximum charging current from the grid to the battery.
   (Note: This value refers to the battery-side current, not the grid-side current, and does not apply to scheduled charging.)
- Max. chg. curr. by gen.: Set the maximum charging current from the generator to the battery.
   (Note: This value refers to the battery-side current, not the generator-side current, and does not apply to scheduled charging.).
- Max. chg. current: Set the maximum charging current during the constant current phase of battery charging.
- Batt. curr. stop chg.: During the constant voltage charging phase, charging will cease when the charging current falls below this value. (Effective when BMS communication is not performed or BMS communication fails).

**Note:** After the battery is fully charged, the inverter stops charging. Charging will resume when the battery SOC drops below this value. (Fixed at Battery Charging Stop SOC - 5%, non-modifiable, effective when BMS communication is normal)



## 5.2.3.3 Battery Discharging



 Batt. under volt. alarm: When the battery voltage is lower than this value, the inverter will report an under-voltage alarm (notifying the user that the battery is about to stop discharging), but the battery will not stop discharging. (Effective when BMS communication is not established or fails.)

- Batt. under capacity alarm: SOC value up to this setting will alarm. The inverter output will not shut down and the fault disappears if the SOC value exceeds 5% of the set value. (Valid when BMS communication is normal)
- Batt. volt low recovery: When the battery report voltage low fault, the battery voltage reach this setting, the fault will be cleard.
- Batt. SOC low fault: When the battery SOC is lower than this value, the inverter will report a low battery SOC fault and stop discharging. (Effective when BMS communication is normal.)
- Batt. voltage low fault: When the battery voltage is lower than this value and after the "Discharge Stop Delay Time" elapses, the inverter will report a low battery voltage fault and stop discharging.
- Batt. volt. low delay: Battery stop discharge delay time.
- Batt. max. curr. dischg.: Set the max. battery discharger current.


#### The following settings are only effective in hybrid grid operation mode:

- Batt. volt. stop dischg. in hybrid: Discharging stops when the battery voltage is lower than this
  value. (Effective when BMS communication is not established or fails.)
- Batt. SOC stop dischg. in hybrid: Discharging stops when the battery SOC is lower than this value. (Effective when BMS communication is normal.)
- Batt. volt. restart dischg. :The inverter stops discharging after low battery voltage, and resumes
  discharging when the battery voltage rises above this value. (Effective when BMS communication is
  not established or fails.)
- Batt. SOC restart dischg.: The inverter stops discharging after low battery capacity, and resumes
  discharging when the battery SOC rises above this value. (Effective when BMS communication is
  normal.)



# 5.2.4 Grid Connection Settings

## 5.2.4.1 Basic Page




- Grid frequency: Select the local grid frequency (50Hz/60Hz).
- Sell Power Max: Set the maximum power for feeding into the grid.
- Buy Power Max: Maximum power drawn from the grid. If the grid charging power + load power by the grid exceeds this setting, the inverter will prioritize reducing the grid charging power to avoid exceeding the buying power threshold.
- External CT ratio: When connecting an external CT, enter the ratio on the CT specification. (CT is fixed for grid-side power collection.)
- zero-export power: Error calibration power for anti-backflow, recommended to be set between 20-100W.Due to sampling accuracy issues, in order to bring the anti-backflow side power close to 0W:
  - ① When buying power P > 0, set this value to P;
  - ② When selling power P > 0, set this value to -P.
- On Grid Reactive Power: Setting range 0-100%, expressed as a percentage of reactive power.
- Reactive power over/under excited: "over" indicates 0%-100% / "under" indicates -100% ~ 0%.
- On Grid PF: Setting range 0.8 ~ 1.
- Reactive power over / under excited: "over" indicates 0.8 ~ 1 / "under" indicates -0.8 ~ -1
- Grid standard (subject to the actual display on the screen.):

Austria: TE-OVE	Thailand: PEA-MEA PEA-MEA	Italy: CEI 0-21:2022/V1:2022	
Germany: VDE-AR-N 4105:2018	Europe: EN 50549-1	Spain: UNE 217002: 2020-10	
United States: IEEE Std 1547 203	Great Britain: G99		
South Africa: NRS097	Australia: AS4777.2 Australia A	Myanmar;	
Poland: EN 50549-1	Australia: AS4777.2 New Zealand	Thailand: PEA-MEA	
Ireland: EN50549-IE	United States: UL1741	Northern Ireland: G99/NI	
Great Britain: G98	Puerto Rico	Uninitialized	




# **5.2.4.2 Enter Service** (This setting is not recommended to be changed by the customer)



- Enter service enable: Grid connection startup setting (enabled by default).
- Connect voltage low: Minimum voltage requirement for grid connection.
- Connect frequency low: Minimum frequency requirement for grid connection.
- Connect voltage high: Maximum voltage requirement for grid connection.
- Connect frequency high: Maximum frequency requirement for grid connection.
- Normal connect delay time: The delay time for the inverter to connect to the grid when the grid first meets the connection requirements.
- Normal connect power ramp rate: The ramp rate of grid-connected power for the first grid connection.
- Reconnect delay time: Grid disconnection and reconnection, grid connection delay time.
- Reconnect power ramp Rate: Grid disconnection reconnection, rate of rise of grid-connected power.

# **5.2.4.3 Grid Protection** (It is not recommended for users to change this suggested item)



- Time: Time Protection Response Time.
- LV1:

Class 1 undervoltage protection point. When the grid voltage drops below this threshold and remains so for the corresponding protection response time, the inverter shall disconnect from the grid.

#### • LF1:

Class 1 underfrequency protection point.

When the grid frequency drops below this threshold and remains below it for the corresponding protection response time, the inverter shall disconnect from the grid.

• LV2:

Class 2 undervoltage protection point.

When the grid voltage drops below this threshold and remains below it for the corresponding protection response time, the inverter shall initiate grid disconnection.

• LF2:

Class 2 underfrequency protection point.

When the grid frequency drops below this threshold and remains below it for the corresponding protection response time, the inverter shall disconnect from the grid.



#### • HV1:

Class 1 overvoltage protection point.

When the grid voltage rises above this threshold and remains above it for the corresponding protection response time, the inverter shall disconnect from the grid.

#### • HF1:

Class 1 overfrequency protection point.

When the grid frequency exceeds this threshold and remains above it for the corresponding protection response time, the inverter shall disconnect from the grid.

#### • HV2:

Class 2 overvoltage protection point.


When the grid voltage exceeds this threshold and persists above it for the preconfigured protection response time, the inverter shall initiate grid disconnection.

#### • HF2:

Class 2 overfrequency protection point.

When the grid frequency exceeds this threshold and remains above it for the specified protection response time, the inverter shall disconnect from the grid.

## 5.2.4.4 Others (It is not recommended for users to change this suggested item)



Volt-Watt (V-P) curve enable:

Regulates the active power of the inverter according to the set grid voltage.

Volt-Var (V-Q) curve enable:
 Adjustment of the inverter reactive

/ LV ride-through values.

- power according to the set grid voltage.LVRT/HVRT enable:Adjustment of the grid HV ride-through
- LFRT/HFRT enable: According to the preset grid high-frequency/low-frequency ride-through thresholds.
- Watt-Var (P-Q) curve enable: Adjustment of the inverter reactive power according to the set active power.
- Watt-PF (P-PF) curve enable: Adjustment of the inverter power factor according to the set active power.
- Frequency Droop (F-P) enable: Adjustment of inverter output power according to grid frequency.
- DRM Enable: Australia only.



# 5.2.5 Advanced Settings

#### 5.2.5.1 Generator





#### • Generator work mode:

- ① **Generator input:** When the generator is connected to the "Gen port", select the "Generator input".
- ② **Micro inverter input:** When the gridtied inverter is connected to the "Gen Port" of the hybrid inverter, select the "Microinverter Input".
- ③ Smart load: When the load is connected to the "Gen port", select "Smart load output".
- Grid always to smart load enable: When the inverter operates in hybrid grid mode, the smart load remains constantly enabled.
- **Generator rate power:** Setting the rated power of the generator.
- Off-grid disconnect smart load: When the inverter operates in off-grid mode, the smart load shall be immediately disabled.
- Turn on the smart load SOC: When battery SOC > this value, enable smart load. (Effective when BMS communication is normal)
- Turn off the smart load SOC: When battery SOC < this value, disable smart load. (Effective when BMS communication is normal).
- Turn on the smart load voltage: When battery voltage > this value, enable smart load. (Effective when BMS communication is not established or fails)
- Turn off the smart load voltage: When battery voltage < this value, disable smart load. (Effective
  when BMS communication is not established or fails).</li>
- Dry contact function setting: ① Generator control. ② PV on grid energy monitoring.
   ③ Grid voltage monitoring.
- **Grid voltage monitoring threshold:** When the grid voltage exceeds the threshold, the dry contact operates.
- PV on grid energy monitoring threshold: When the PV grid-connected energy exceeds the threshold, the dry contact operates.




#### 5.2.5.2 Wind Turbine Settings



- MPPT1/2/3: Enable for wind turbine input.
- V1/2/3/4.../14: Voltage parameters for the wind turbine.
- C1/2/3/4.../14: Current parameters for the wind turbine.

#### 5.2.5.3 Other





#### • CT manual setting:

Select the CT direction based on the CT installation (ensure that the direction of each phase CT is consistent).

- ① When the arrow on the CT points to the inverter, set it to "Point to Inverter".
- ② When the arrow on the CT points to the grid, set it to "Point to Grid".
- Electric meter options: Whether to enable three-phase meter.
- PE-N Connect enable: Enable automatic switching of PE-N connections.
- PV Riso check enable: Enable PV insulation impedance detection.
- Leakage curr. protection enable: Enable leakage current protection.
- Power saveing mode: When the energysaving mode is activated:
  - ① If the load power is less than 35W, the inverter output will turn off after 5 min;
  - ② If the load power is greater than 56W, the inverter output will restart immediately.

MPPT scan: When this function is enabled: The inverter will perform an MPPT global scan every 30 min. During the scan, the photovoltaic power will drop to 0W and then reach the maximum power point.


**Note:** Applicable to scenarios where the photovoltaic panels cannot output maximum power due to shading or other reasons.

- Smart Meter 1 Address
- AFCI check threshold
- Arc fault clear



- Smart meter connect point: Select the corresponding object based on the power to be collected by the meter.
  - ① When the meter is required to collect micro-inverter power, select "Micro inverter" (valid only when the micro-inverter is connected to the grid side);
  - ② When the meter is required to collect grid power, select "Grid".


#### 5.2.5.4 Restart



#### 5.2.6 LCD Display WIFI Setting

#### 5.2.6.1 Search and Select Network

Click the [Refresh] button, select the target network name from the hotspot list, and click to enter the password input interface.






#### 5.2.6.2 Enter and Verify Password

Enter the WIFI network password (supporting numbers and letters) in the password input field; click [Connect] to confirm and establish the connection.



- Cancel: Exit the password data interface.
- Connect: Connect to the WIFI network.

#### 5.2.7 Firmware Upgrade via USB Drive



- ② **0**: Normal/CPU1 for upgrading the inverter is primary CPU1 program.
- ③ 1: CPU2 for upgrading the inverter is primary CPU2 program.
- 4 2: AUX DSP for upgrading the inverter is auxiliary DSP program.
- 5 3: AFCI MCU for upgrading the AFCI chip program.
- (6) 4: BMS MCU for upgrading the battery BMS program.

- Cancel: Cancel the upgrade.
- Upgrade: Update the firmware.

## 5.3 Time-slot Charging/Discharging Function

The IESP UH3 series have the function of charging and discharging by different time periods. Users can set different charging and discharging time periods according to the local peak and valley electricity prices, so as to make rational use of the utility power and photovoltaic energy. When the utility power price is expensive, the battery inverter can be used to supply electricity to the load. When the utility power price is low, the utility power can be used to supply power to the load and charge the battery, which can help users save electricity bills to the greatest extent.




Users can enable or disable the time-slot charging and the time-slot discharging functions in the settings menu, and configure the charging and discharging periods, including the scheduled grid-charging start time and duration, as well as the scheduled battery-discharging start time and duration.

The following is an example to assist users in understanding this feature.

Before using this function for the first time, please set the local time in the parameters menu; afterwards, Users can set corresponding time periods according to the electricity prices during peak and off-peak hours in the local area.

The device also supports configuring battery discharge outside the scheduled discharge periods.



# Time-slot Utility Charging & Loading Function Time-slot Battery Discharging Function Time-slot Battery Discharging Function

With 3 definable periods, the user can freely set the mains charging/supplying power time within the range of 00:00 to 23:59. During the time period set by the user, if PV energy is available, PV energy will be used first, and if PV energy is not available or insufficient, utility energy will be used as a supplement.

With 3 definable time periods, users can freely set the battery discharge time within the range of 00:00 to 23:59. During the time set by the user, the inverter will give priority to the battery inverter to carry the load, and if the battery power is insufficient, the inverter will automatically switch to mains power to ensure stable operation of the load.



## **5.4 Battery Parameters**

## **5.4.1 Lead-acid Battery**

Battery type	Sealed lead acid battery	Gel lead acid battery	Flooded lead acid battery	User-defined (USE)	Adjustable
Parameters	(SLD)	(GEL)	(FLD)	(00-)	
Overvoltage Disconnect Voltage	60V	60V	60V	60V	
Battery fully charged recovery point	52V	52V	52V	52V	√
Boost Charging Voltage	57.6	57.6	57.6	40 ~60V	√
Undervoltage Alarm Voltage	44V	44V	44V	40 ~60V	√
Undervoltage Alarm Recovery Voltage	ı	Undervoltage ala	ırm voltage+0.8\	l	
Low Voltage Disconnect Voltage	42V	42V	42V	40 ~60V	√
Low Voltage Disconnect Recovery Voltage	52V	52V	52V	52V	√
Discharge Limit Voltage	57.6	57.6	57.6	40 ~60V	√
Over-discharge Delay Time	5s	5s	5s	1 ~30s	√
Boost Charge Duration	120 min	120 min	120 min	10 ~ 900 min	√

## 5.4.2 Lithium-ion Battery


Battery type Parameters	Ternary (N13)	Ternary (N14)	LFP (L16)	LFP (L15)	LFP (L14)	Adjustable
Overvoltage Disconnect Voltage	60V	60V	60V	60V	60V	
Battery Fully Charged Recovery Point	50.4V	54.8V	53.6V	50.4V	47.6V	<b>√</b>
Equalization Charging Voltage	-	-	-	-	-	<b>√</b>
Boost Charging Voltage	53.2V	57.6V	56.8V	53.2V	49.2V	V
Undervoltage Alarm Voltage (Fault 01)	43.6V	46.8V	49.6V	46.4V	43.2V	√
Undervoltage Alarm Recovery Voltage (Fault 01)		Undervolt	age alarm vo	ltage+0.8V		
Low Voltage Disconnect Voltage (Fault 04)	38.8V	42V	48.8V	45.6V	42V	√
Low Voltage Disconnect Recovery Voltage (Fault 04)	46V	49.6V	52.8V	49.6V	46V	√




Discharge Limit Voltage	36.4V	39.2V	46.4V	43.6V	40.8V	<b>√</b>
Over-discharge Delay Time	30s	30s	30s	30s	30s	√
Boost Charge Duration	120 min	<b>√</b>				

## 6. Communication

## **6.1 Product Overview**






9	Grid CT1	10	Microinverter CT2	11	DRM Port		
12	485/Meter Port	13	485/WiFi Port	14	485/EMS Port		
15	Display USB-2	16	USB-1 Port	18	CAN Communication Port		
19	Parallel Port-B	20	Parallel Port-A	21	CAN/BMS2 Communication Port		
22	22 CAN/485/BMS1 Communication Port						




#### 6.2 USB-1 Port


The user can read and modify device parameters through this port by using the host software. Please contact us for the host software installation package if you require one.



#### **6.3 WIFI Communication Function**

The WIFI port is used to connect to the Wi-Fi/GPRS logger module, which allows users to view the operating status and parameters of the inverter via mobile phone APP.






RJ45	Pin 1	Pin 2	Pin 3	Pin 4	Pin 5	Pin 6	Pin 7	Pin 8
Definition	5V	GND	/	/	/	/	RS485-A	RS485-B



#### 6.4 RS485 Port

The RS485/CAN/BMS1 interface is used to connect to the BMS lithium battery.



RJ45	Pin 1	Pin 2	Pin 3	Pin 4	Pin 5	Pin 6	Pin 7	Pin 8
Definition	RS485-B	RS485-A	/	CANH	CANL	/	RS485-A	RS485-B


CAN/485/BMS1

NOTICE

If you need to use the inverter to communicate with the lithium battery BMS, please contact us for the communication protocol or upgrade the inverter to the appropriate software programme.

#### 6.5 CAN Port


The CAN port is used to connect to the BMS of lithium battery.




RJ45	Pin 1	Pin 2	Pin 3	Pin 4	Pin 5	Pin 6	Pin 7	Pin 8
Definition	/	/	/	CANH	CANL	/	/	/

## 6.6 Display Port USB-2

It is used to updated the screen firmware.



## 6.7 DRM(Only Australia)



RJ45	Pin 1	Pin 2	Pin 3	Pin 4	Pin 5	Pin 6	Pin 7	Pin 8
Definition	DRM5	DRM6	DRM7	DRM8	RefGen	COM/ DRM0	V+	V-


DRM

MODEL	RJ45 socket asserted by shorting pins		Requirement
DRM0	5	6	Operate the disconnection device.
DRM5	1	5	Do not generate power to grid.
DRM6	2	5	Do not generate at more than 50% of rated power.
DRM7	3	5	Do not generate at more than 75% of rated power AND Sink reactive power if capable.
DRM8	4	5	Increase power generation (subject to constraints from other active DRM) .




#### 6.8 External CT Prot

⚠ **Important Note:** CT1 is used for grid-side current monitoring and must be reliably connected to the main grid circuit to ensure matching with system electrical parameters; CT2 should be accurately connected to the AC output terminal of the micro-inverter for real-time monitoring of the inverter's current output status.



- 1.Split Core Current Transformer (CT) dimension: (mm)
- 2.Secondary output cable length is 4m.





## **6.9 DIP Switch Configuration**




This DIP switch is a resistor matching switch for parallel communication. When performing parallel CAN communication, the first and last units in the parallel system must have DIP switches 1 and 2 toggled down.

## **6.10 Dry Contact Function**

#### The dry contact port has 5 functions:

- 1.Generator remote start/stop
- 2.Temperature sampling (reserved)
- 3.RSD power supply
- 4. Remote signal transmission
- 5.Remote signal reception



1 2 3 4 5 6 7 8 9

Function	Definition
Remote start/stop of the generator	1-2: NC; 1-3: NO Remote generator shutdown: Pins 1 to 2 are normally closed; pins 1 to 3 are normally opened.
Temperature sampling (reserved)	Pins 9 and 5 can be used for battery temperature sampling compensation.
RSD power supply	Pin 9 is GND, pin 4 is RSD 12V+.
Remote signal transmission	Pins 9 and 7/8: DSP internal signal transmission.
Remote signal reception	Pins 9 and 6: DSP internal signal reception.



If you need to use the remote start/stop function of the generator with dry contact, ensure that the generator has ATS and supports remote start/stop.



## 7. Fault Codes and Countermeasures

## 7.1 Fault Codes

Fault Code	Fault name	Whether it affects the output or not	Description
01	BatVoltLow	NO	Battery undervoltage alarm.
02	BatOverCurrSw	YES	Battery discharge average current overcurrent (software protection).
03	BatOpen	YES	Battery not-connected alarm.
04	BatLowEod	YES	Battery undervoltage stop discharge alarm.
05	BatOverCurrHw	YES	Battery overcurrent (hardware protection).
06	BatOverVolt	YES	Charging overvoltage protection.
07	BusOverVoltHw	YES	Bus overvoltage (hardware protection).
08	BusOverVoltSw	YES	Bus overvoltage (software protection).
09	PvVoltHigh	NO	PV overvoltage protection.
10	ArcFault	YES	AFCI Arc fault.
11	PvBoostOCHw	NO	Boost overcurrent hardware protection.
12	SpiCommErr	YES	Master-slave SPI communication failure.
13	Overload Bypass	YES	Bypass overload protection.
14	Overload Inverter	YES	Inverter overload protection.
15	AcOverCurrHw	YES	Inverter overcurrent hardware protection.
16	AuxDSpReqOffPWM	YES	Slave chip OFF request fault.
17	InvShort	YES	Inverter short circuit protection.
18	Bussoftfailed	YES	Bus soft-start failure.
19	OverTemperTrans	YES	Transformer radiator over-temperature protection.
20	OverTemperInv	YES	Inverter radiator over-temperature protection.
21	FanFail	YES	Fan failure.
22	EEPROM	YES	Memory failure.
23	Model NumErr	YES	Model setting error.
24	Busdiff	YES	Positive and negative bus voltage imbalance.
25	BusShort	YES	Bus short circuit.
26	Rlyshort	YES	Inverter AC output backfeed to bypass AC output.
27	LinePhaselose	YES	Grid input phase lose.



28	LinePhaseErr	YES	Grid input phase error.
29	BusVoltLow	YES	Low bus voltage protection.
30	BatCapacityLow1	NO	Alarm given when battery capacity rate is lower than 10% (setting BMS to enable validity).
31	BatCapacityLow2	NO	Alarm given when battery capacity rate is lower than 5% (setting BMS to enable validity).
32	BatCapacityLowStop	YES	Inverter stops when battery capacity is low (setting BMS to enable validity).
33	ControlCanFault	YES	Control CAN fault in parallel operation.
34	CanCommFault	YES	CAN communication fault in parallel operation.
35	ParaAddrErr	YES	Parallel ID (communication address) setting error.
36	Balance currentOC	YES	Balanced bridge arm overcurrent fault.
37	ParaShareCurrErr	YES	Current distribution fault in parallel operation.
38	ParaBattVoltDiff	YES	Parallel mode, inconsistent utility input source.
39	ParaAcSrcDiff	YES	Inconsistent AC input source in parallel mode.
40	ParaHwSynErr	YES	Hardware synchronization signal error in parallel mode.
41	InvDcVoltErr	YES	Inverter DC voltage error.
42	SysFwVersionDiff	YES	Inconsistent system firmware version in parallel mode.
43	ParaLineContErr	YES	Parallel line connection error in parallel mode.
44	Serial number error	YES	No serial number set at factory.
45	Error setting of split- phase mode	YES	Item "Parallel" setting error.
49	Grid over voltage	YES	Grid voltage too high.
50	Grid under voltage	YES	Grid voltage too low.
51	Grid over Frequency	YES	Grid frequency too high.
52	Grid under Frequency	YES	Grid frequency too low.
53	Grid loss	YES	Grid voltage loss.
54	Grid DC current over	YES	Excessive DC component in grid current.
55	Grid standard un init	YES	Grid-Connection standard micro-initialization.
56	Low insulation resistance fault	NO	PV1+, PV2+, PV3+, PV- impedance to ground abnormally low.
57	Leakage current overload fault	YES	System leakage current exceeds the standard.
58	BMSComErr	NO	BMS communication error.



60	BMSUnderTem	NO	BMS low temperature alarm (effective after
			successful BMS communication).
61	BMSOverTem	YES	BMS over-temperature alarm (effective after
	Divide ver reini	. 23	successful BMS communication).
60	DN4CO C	VEC	BMS overcurrent alarm (effective after successful
62	BMSOverCur	YES	BMS communication).
62	BMSUnderVolt	NO	BMS undervoltage alarm (effective after successful
63	Divisoriaervoit	NO	BMS communication).

## 7.2 Troubleshooting

Fault	Meaning	Causes	Remedy
Code			
/	No screen display	No power input, or the switch on the bottom of the unit is not switched on.	Check whether the battery air circuit-breaker or PV air circuit-breaker is turned on. Check if the switch is "ON". Press any button on the screen to exit the screen sleep mode.
01	Battery under-voltage	Battery voltage is lower than the parameter setting value.	Wait until the battery charge is restored to above the low voltage disconnection recovery voltage.
03	Battery not connected	The battery is not connected, or the BMS is in discharge protection state.	Check that the battery is reliably connected. Check that the battery circuit-breaker is off. Ensure that the BMS is able to communicate properly.
04	Battery over- discharge	The battery voltage is lower than the value set in [Battery Settings] - [Battery Discharge] - [Batt. voltage low fault].	Manual reset: Turn off and restart.  Automatic reset: Charge the battery so that the battery voltage is higher than the voltage set in the parameter item 【Battery Settings】 - 【Battery Discharge】 - 【Battery Recovery Voltage】.
06	Battery over-voltage when charging	Battery is in over- voltage condition.	Manually power off and restart.  Check to see if the battery voltage exceeds the limit. If it exceeds, the battery needs to be discharged until the voltage is below the battery over-voltage recovery point.
13	Bypass over-load (software detection)	Bypass output power or output current over-load for a period of time.	Deduce the lead power and restart the device
14	Inverter over- load(software detection)	Inverter output power or output current over-load for a period of time.	Reduce the load power and restart the device.



19	Heat sink of PV input over-temperature (software detection )	Heat sink of PV input temperature exceeds 90°C for 3s.	Normal charging and discharging is resumed when the temperature of the heat sink cools
20	Heat sink of inverter output over-temperature (software detection)	Heat sink of inverter output temperature exceeds 90°C for 3s.	below the over-temperature recovery temperature.
21	Fan failure	Hardware detects fan failure.	Manually toggle the fan after powering off the machine to check for foreign matter blockage.
26	AC input relay short- circuit	Relay for AC input sticking.	Manually turn off and restart the machine, if the fault reappears after restarting, you need to contact the after-sales service to repair the machine.
28	Utility input phase fault	AC input phase does not match AC output phase.	Make sure that the phase of the AC input is the same as the phase of the AC output.

#### NOTICE

If you encounter product faults that cannot be solved by the methods in the above table, please contact our after-sales service department for technical support and do not disassemble the equipment by yourself.

## 8. Protection and Maintenance

#### **8.1 Protection Functions**

No.	Protection Functions	Description
1	PV input current limiting protection	When the charging current or power of the PV array configured exceeds the PV input rated value, the inverter will limit the input power and charge at the rated.
2	PV input over-voltage	If the PV voltage exceeds the maximum value allowed by the hardware, the machine reports a fault and stops PV boosting to output a sinusoidal AC waveform.
3	Anti-reverse charge protection at night	At night, the battery will be prevented from discharging to the PV module because the battery voltage is greater than the PV module voltage.
4	AC input over-voltage protection	When the mains voltage exceeds 140Vac, mains charging will stop and the inverter will switch to output mode.
5	AC input under-voltage protection	When the mains voltage falls below 90Vac, mains charging will stop and the inverter will switch to output mode.



		When the battery voltage reaches the over-voltage disconnection
6	Battery over-voltage	voltage point, it will automatically stop the PV and mains
	protection	charging of the battery to prevent over-charging and damage to
		the battery.
	Battery under-voltage	When the battery voltage reaches the low-voltage disconnection
7	protection	voltage point, it will automatically stop discharging the battery to
	protection	prevent the battery from being over-discharged and damaged.
	Battery over-current	When the battery current exceeds the range allowed by
8	protection	hardware, the machine will turn off output and stop discharging
	protection	the battery.
		When a short-circuit fault occurs at the load, the AC output
	AC output short-circuit	voltage will be switched off immediately and output again after 1
9	protection	min. If the output load is still short-circuited after 3 attempts,
	protection	short-circuit fault of the load must be eliminated first and then
		manually re-powered in order to restore the normal output.
		When the internal temperature of the inverter is too high, the
10	Heat sink over-temperature	inverter will stop charging and discharging; when the
	protection	temperature returns to normal, the inverter will resume charging
		and discharging.
11	AC output reverse	Prevents backfeeding of battery inverter AC to bypass AC inputs.
12	Bypass over-current	Built-in AC input overcurrent protection circuit breaker.
12	protection	built-in AC input overcurrent protection circuit breaker.
		When the phase of the two bypass inputs is different from the
13	Bypass phase inconsistency	phase of the inverter phase split, the machine will prohibit
13	protection	cutting into the bypass to prevent the load from dropping out or
		short-circuiting when cutting into the bypass.



#### 8.2 Maintenance

## To maintain optimum long-lasting working performance, it is recommended that the following items be checked twice a year.

- 1. Ensure that the airflow around the inverter is not blocked and remove any dirt or debris from the radiator.
- Check that all exposed conductors are not damaged by sunlight, friction with other surrounding objects, dry rot, insect or rodent damage, etc. The conductors need to be repaired or replaced if necessary.
- 3. Verify that the indications and displays are consistent with the operation of the equipment, note any faults or incorrect displays and take corrective action if necessary.
- Check all terminals for signs of corrosion, insulation damage, high temperatures or burning/discolouration and tighten terminal screws.
- 5. Check for dirt, nesting insects and corrosion, clean as required, clean insect screens regularly.
- 6. If the lightning arrester has failed, replace the failed arrester in time to prevent lightning damage to the inverter or other equipment of the user.



Make sure that the inverter is disconnected from all power sources and that the capacitors are fully discharged before carrying out any checks or operations to avoid the risk of electric shock.

#### The Company shall not be liable for damage caused by :

- 1. Damage caused by improper use or use in a wrong location.
- 2. PV modules with an open-circuit voltage exceeding the maximum permissible voltage.
- 3. Damage caused by the operating temperature exceeding the restricted operating temperature range.
- 4. Dismantling and repair of the inverter by unauthorised persons.
- 5. Damage caused by force majeure: damage during transport or handling of the inverter.



## 9. Datasheet

Models	HESP48140UH3	HESP48160UH3	HESP48180UH3	Adjustable
AC Output (Load)				
Rated Output Power	14000W	16000W	18000W	
Max. Peak Power	28000VA	32000VA	36000VA	
Rated Output Voltage	12	20/208Vac (Three-ph	ase)	√
Output Voltage Error		± 5%		
Rated Frequency		50/60Hz ± 0.3Hz		√
Waveform		Pure sine wave		
Switch Time		10ms (Typical)		
AC Output (On-grid)	I			
Rated Output Power	14000W	16000W	18000W	
Max. Apparent Power	15400VA	17600VA	19800VA	
Power Factor	C	0.8 leading to 0.8 lagg	ing	
Rated Output Voltage		3L/N/PE 120/208Va	ıc	
Rated AC Frequency		50/60Hz		
Rated AC Output Current	38.8Aac	44.5Aac	50Aac	
THD		<3%		
Battery Data				
Battery Type	Lithium-ion Bat	tery / Lead-acid Batte	ery / User-defined	√
Rated Battery Voltage		48Vdc		
Battery Voltage Range		40-60Vdc		
Max. Generator Charging Current	300Adc	330Adc	350Adc	V
Max. Grid Charging Current	300Adc	330Adc	350Adc	√
Max. Hybrid Charging Current	300Adc	330Adc	350Adc	√
Charging Strategy for Li-ion Battery		Self-adaption to BM	S	
PV Input				
No. of MPPT Trackers		3		
No. of Strings MPPT Tracker		2+2+2		



Max. PV Access Power	28000W	32000W	36000W	
Max. PV Input Power	22400W	25600W	28800W	
Max. PV Input Current	40A/40A/40A			
Max. Input Short-Circuit Current		55A/55A/55A		
Max. PV Input Voltage		600V		
MPPT Operating Voltage Range		120V ~ 500V		
Grid/Generator Input				
Input Voltage Range	Phase Voltage	: 90V~140V; Line Volta	age: 156V~243V	
Input Frequency Range		40-70Hz		
Max. Bypass Overload Current (Grid)		200A		
Efficiency				
MPPT Tracking Efficiency		99.9%		
Max. Efficiency		≥97.5%		
European Efficiency		97%		
Protection				
PV Input Lightning Protection	Yes			
Anti-islanding Protection		Yes		
PV Input Reverse Polarity Protection	Yes			
Insulation Resistor Detection	Yes			
Residual Current Monitoring Unit	Yes			
Output Over Current Protection	Yes			
Output Shorted Protection	Yes			
Surge Protection	DC type II/AC type II			
Overvoltage Category	DC type II/AC type III			
Certification				
Certificate	UL 1741-2021 (UL1741SB), CSA C22.2 No 107.1-16, IEEE 1547-2018 & 1547a-2020 & 1547.1-2020 (SRD V2.0) UL 1741 CRD-PCS, UL1699B, CEC, SGIP, CSIP			
			C, SGIP, CSIP	



General Data		
Parallel Capacity	9	
Operating Temperature	-25 ~ 60°C, >45°C derated	
Humidity Range	0~100%	
Noise	<55dB	
Protection Degree	IP65	
Cooling Method	Heat sink + intelligent air cooling	
Standby Power Consumption	<100W	
Dimensions	860x480x313mm	
Weight	59kg	
Communication Interface	RS485 / CAN / USB / Dry contact	√
External Modules	Wi-Fi / 4G Stick (Optional)	√



## **SRNE Solar Co,.Ltd**

Mail	service@szshuori.com	
Web	www.srnesolar.com	
	4-5F,Building13A,Taihua Wutong	
A al al	Industrial Park ,Gushu Development	
Address	Zone , Hangcheng Street,Baoan,	
	Shenzhen, China PR	